


Reinforced Concrete

- Material Properties
 - Aggregate
 - Cement
 - Water
 - Reinforcement
- Strength
 - Compression, f'_c
 - Tension, f'_t
- PCA – Concrete Fundamentals



Constituents of Concrete

- **Aggregate**
- Cement
- Water

Fine aggregate
(Sand)
 $\leq 1/4"$



coarse aggregate
 $\sim 3/8"$ (small)



coarse aggregate
 $\sim 1/2"$ to $1"$ (medium)

coarse aggregate
 $\sim 1.5"$ (large)

Constituents of Concrete

- **Aggregate**
- Cement
- Water

Characteristics:

- Abrasion resistance
- Freezing resistance
- Sulfate resistance
- Alkali resistance
- Shape and texture
- Grading
- Void content
- Density
- Moisture absorption
- Flexural strength



crushed stone



smooth "river rock"

Constituents of Concrete

- Aggregate
- **Cement**
- Water

Ingredients:

- Limestone
- Cement rock
- Clay
- Iron ore
- + (after firing and grinding)
- gypsum



Cement Types

- • **Type 1**
normal portland cement. Type 1 is a **general use** cement.
- **Type 2**
is used for structures in water or soil containing **moderate amounts of sulfate**, or when heat build-up is a concern.
- • **Type 3** *WINTER*
high early strength. Used when high strength are desired at very early periods.
- **Type 4** *THICK SLABS*
low heat portland cement. Used where the amount and rate of heat generation must be kept to a minimum.
- **Type 5**
Sulfate resistant portland cement. Used where water or soil is high in alkali.
- Types IA, IIA and IIIA are cements used to make air-entrained concrete.

Constituents of Concrete

- Aggregate
- Cement
- **Water**
 - “potable”
 - No sulfates or organic impurities

Add mixtures:

- Air-entraining ✓
- Water-reducing } *INCREASE*
- Plasticizers } *STRENGTH*
- Accelerating ✓
- Retarding ✓
- Hydration control
- Shrinkage reducer ✓
- Alkali-silicate inhibitor
- Coloration |
- Bonding |
- Foaming |
- And others...



Constituents of Concrete

batch guidelines

Common Concrete Mix Ratios:

1:2:3 (Cement:Sand:Gravel):

This is a widely used ratio for general construction, offering a good balance of strength and workability.

1:1.5:3 (Cement:Sand:Gravel):

Another popular option, especially for foundations and beams, offering a good balance of strength and durability.

1:4:8 (Cement:Sand:Gravel):

This ratio is preferred for foundations and mass concrete work.

1:1:2 (Cement:Sand:Gravel):

This ratio is used for construction work that requires high-strength concrete.

Constituents of Concrete

PCA batch tables w/c

Table 9-16 (Inch-Pound). Proportions by Mass to Make One Cubic Foot of Concrete for Small Jobs

Nominal maximum size coarse aggregate, in.	Air-entrained concrete				Non-air-entrained concrete			
	Cement, lb	Wet fine aggregate, lb	Wet coarse aggregate, lb*	Water, lb	Cement, lb	Wet fine aggregate, lb	Wet coarse aggregate, lb	Water, lb
? $\%0.36$	29	53	46	10	29	59	46	11
$\frac{1}{2}$ 0.37	27	46	55	10	27	53	55	11
$\frac{3}{4}$	25	42	65	10	25	47	65	10
1	24	39	70	9	24	45	70	10
$1\frac{1}{2}$ 0.39	23	38	75	9	23	43	75	9

*If crushed stone is used, decrease coarse aggregate by 3 lb and increase fine aggregate by 3 lb.

Table 9-17. Proportions by Bulk Volume* of Concrete for Small Jobs

Nominal maximum size coarse aggregate, mm (in.)	Air-entrained concrete				Non-air-entrained concrete			
	$\frac{.5}{1}$.5 Cement	Wet fine aggregate	Wet coarse aggregate	Water	Cement	Wet fine aggregate	Wet coarse aggregate	Water
9.5 ($\frac{3}{8}$)	1	$2\frac{1}{4}$	$1\frac{1}{2}$	$\frac{1}{2}$	1	$2\frac{1}{2}$	$1\frac{1}{2}$	$\frac{1}{2}$
12.5 ($\frac{1}{2}$)	1	$2\frac{1}{4}$	2	$\frac{1}{2}$	1	$2\frac{1}{2}$	2	$\frac{1}{2}$
19.0 ($\frac{3}{4}$)	1	$2\frac{1}{4}$	$2\frac{1}{2}$	$\frac{1}{2}$	1	$2\frac{1}{2}$	$2\frac{1}{2}$	$\frac{1}{2}$
25.0 (1)	1	$2\frac{1}{4}$	$2\frac{3}{4}$	$\frac{1}{2}$	1	$2\frac{1}{2}$	$2\frac{3}{4}$	$\frac{1}{2}$
37.5 ($1\frac{1}{2}$)	1	$2\frac{1}{4}$	3	$\frac{1}{2}$	1	$2\frac{1}{2}$	3	$\frac{1}{2}$

*The combined volume is approximately $\frac{2}{3}$ of the sum of the original bulk volumes.

Constituents of Concrete

W/C ratios

Understanding the w/c Ratio:

- **Definition:** The w/c ratio is the ratio of the weight of water to the weight of cement used in a concrete mix.
- **Importance:** It's a critical factor in concrete mix design, influencing strength, durability, and workability.
- **How it affects strength:**
 - **Lower w/c ratio:** Leads to higher strength and durability, reduced shrinkage, and lower permeability.
 - **Higher w/c ratio:** Results in lower strength and increased permeability, potentially leading to cracking and reduced durability.
- **Typical Range:** The typical w/c ratio for different grades of concrete mix falls between 0.40 and 0.60.
- **Minimum w/c ratio:** The minimum w/c ratio is 0.30 - 0.35.
- **Workability:** A lower w/c ratio can make the concrete mix stiffer and more difficult to work with, requiring the use of plasticizers or superplasticizers to improve workability.

Constituents of Concrete

W/C ratios - Strength

Concrete Strength and w/c Ratio:

	Water-Cement Ratio (w/c)	Approximate Compressive Strength (psi)	Notes
X	0.8	2000	Fairly <u>weak concrete</u> , more water
}	0.50	—	<u>Maximum</u> for <u>normal strength</u> concrete
	0.45	—	Maximum for high strength concrete
	0.30 - 0.35	—	<u>Minimum</u> w/c ratio
	0.3	<u>Too stiff to handle</u>	Requires superplasticizers

Workability

Measured in inches of “slump” of a molded cone of fresh mix.

- range 1” to 4” with vibration
- 2” to 6” without vibration



Water/Cement Ratio

- range 0.4 to 0.7
- for strength: higher is weaker
- for workability: higher is more workable



Cement Content

- LBS per cubic yard
- range 400-800 lbs/yd³
- dependent on aggregate
- increases cost



Photos by Tano under cc license

Constituents of Concrete

Slump and Workability

Slump and Workability:

Slump Test:

The slump test measures the consistency of fresh concrete by observing how much it settles after being poured into a cone.

Slump Range:

- 0-1 inch (0-25 mm): Very low workability, suitable for dry mixes like pavements.
- 1-2 inches (25-50 mm): Low workability, suitable for foundations with light reinforcement.
- 2-4 inches (50-100 mm): Medium workability, suitable for manually compacted flat slabs.
- 4-7 inches (100-175 mm): High workability, suitable for sections with tight reinforcement or where concrete needs to flow a great distance.

Reinforcing

Grade = Yield strength

- gr. 40 is 40 ksi ✓
- gr. 60 is 60 ksi ← *NORMALLY*
- gr. 75 is 75 ksi *HIGH*

Size in 1/8 inch increments


- #4 is 1/2 inch dia.
- #6 is 3/4 inch dia.

Deformation Patterns

- add to bond with concrete

Minimum Spacing


- between bars (horizontal)
the greatest of the 3
is the minimum
 - Bar diameter ✓
 - 1" ✓
 - 5/4 x max aggregate size
- between layers (vertical)
1"
- cover
 - 3" against soil
 - 1.5"-2" exterior
 - 3/4" interior




Reinforcement of Weidatalbrücke photo by Störfix

Curing

Strength increases with age. The “design” strength is 28 days.



Portland Cement Association



Strength Measurement

Compressive strength



- 12"x6" cylinder
- 28 day moist cure
- Ultimate (crushing) strength

$$\underline{f'_c}$$

Tensile strength

- 12"x6" cylinder
- 28 day moist cure
- Ultimate (failure) strength
- Split cylinder test
- ca. 10% of f'_c

$$\underline{f'_t}$$



Young's Modulus

Depends on density and strength

$$E_c = w_c^{1.5} 33 \sqrt{f'_c}$$

w_c = concrete density

f'_c = concrete compressive strength

For normal weight concrete (144 PCF)

$$E_c = 57000 \sqrt{f'_c}$$

Examples:

f'_c	E_c
10000 psi	5,700,000 psi
8000 psi	5,098,000 psi
6000 psi	4,415,000 psi
4000 psi	3,605,000 psi
3000 psi	3,122,000 psi

